



NOTES

1. Install vertical rebar 6" (150) beyond corbel width for full height of wall each face.
2. Reinforcement details should be reviewed by a local licensed professional engineer.