



**NOTES:**

1. See Section 6 - Engineering in the LOGIX Design Manual for reinforcement details.
2. Install vertical rebar 6" beyond corbel width for full height of wall each face.
3. Reinforcement details should be reviewed by a local licensed professional engineer.