



Use Polyester Stichbond Fabric at corners and around plumbing after applying the first coat of the waterproof membrane

- Ready for Tile, Plaster, or other Finishes
- Second Base Coat
- Second Coat of Waterproof Membrane
- First Coat of Waterproof Membrane
- Fibreglass Mesh
- First Base Coat
- LOGIX ICF as specified. Scuff surface.