



NOTES:

1. See Section 6 – Engineering in the LOGIX Product Manual for reinforcement details.
2. Helpful Hint: Wedge behind beveled block can be a good place to run electrical wires after screws are in place.