

4.6 – WATERPROOFING

Multiply linear footage of walls by the height of backfill. When calculating backfill height, make sure to add enough height to allow the waterproofing materials to extend over the edge of the footing.

Divide this number by the square footage per roll of membrane material to determine the total number of rolls required.

If using a rigid waterproofing board, do not include a footing overlap in you calculations.