

4.7 – PARGING

Parging typically covers from the top of the waterproofing membrane to a height 2" above the bottom edge of the siding.

Multiply the linear footage of wall by height of parging to determine total square footage of parging required.

Divide this number by the square footage per bag of parging material to determine the total number of bags required.